

Welcome to Northern Explorer

Towing

Please make sure before towing that all items inside the RV are secured from movement and placed in their proper place. The fridge does have a strap to keep it from falling out of its location.

1. Make sure that the stabilizer jacks are stowed in their travel stage.
2. Stow and unhook all utilities and awning
3. Using the front tongue jack raises or lower the trailer to attach to tow vehicle.
4. Lower trailer on to hitch.
5. Latch the ball and attach safety chains and emergency brake away cable to vehicle.
6. Attache weight distribution hitch bars and sway control arm.
7. Raise tongue jack all the way up and move extension to its highest point.
8. Plug in trailer lights to vehicle.

Set up & Tear Down

1. Before disconnecting from vehicle, level the trailer axle from side to side.
2. Once trailer is level (left to right) unhook the tow vehicle.
3. Using the tongue jack level the trailer from nose to tail.
4. Once trailer is fully level lower the stabilizer jacks starting with the back two.

Notice: stabilizer jacks are not to be used to level the trailer, they are designed to help with the bounciness of the trailer. Lower till they just hit the ground then add a little pressure.

5. hook up power wire and other available utilities.
 1. Please use the surge protector for power (Never use without)
 2. please use the pressure regulator for water (never use without)
6. Fold out step and set the stair legs to the appropriate length.
7. Start by pressing the Slide “ext/out” button and allow all the slides to extend fully.

DO NOT WALK ON SLIDES WHEN THEY ARE IN

8. Start a camp fire and enjoy!

For tare down follow steps above in reverse order.

Stove top

Make sure the gas (propane tank) is on.

Use a match or lighter to light cook top

Make sure the vent is open when cooking in the RV

Power / Electrical

This unit has a 30amp plug. Which should always be the best to plug into to utilize all the amenities that the RV has to offer.

You are capable of plugging in to a 20amp outlet (standard house outlet) but are limited to some items in the camper. For example, you can run the A/C but not the microwave.

Plugging in to shore power.

1. attach power wire to trailer
2. attach surge protector to power wire
 1. There is an attachment for 20amp (house hold outlet) this would go between the surge protector and the power source.
3. attach surge protector to power source.

to unhook power please follow the steps in reverse order

Water

There are two options when it comes to water

1. Water Tank (35 gal) for use when not hooked to city water.
 1. turn water pump on at control panel by the front door.
 2. Do not leave "on" when not in use
2. City Water
 1. attach 90 degree to RV City Water connection
 2. attach hose to 90 degree attachment
 3. attach Water Filter to other end of hose
 4. attach pressure regulator to water source.
 5. Turn :on: water source.

To disconnect water follow steps above in reverse order.

Hot water tank

This unit comes with a 6 gal gas hot water tank

When not connected to City Water please turn water pump “on” for the duration the water heater is on. Failure to do so will result in injury or damage.

Propane Water Heater

1. Make sure the gas (Propane tank) is on
2. Turn on switch by the entertainment wall.
3. Allow 20 min to heat water in tank. The heater will maintain the temp. once set.

Electric Hot Water

1. There is a switch located outside on the water heater.
2. Remove cover
3. Turn on switch, enjoy

When using electric water heater do not use “Heat” switch inside the unit.

Holding Tanks

There are three tanks for dirty water

1. Gray tank (2)
2. Black tank (1)

Gray tank – this is the dirty water form the sink and shower.

Black tank – this is the dirty water form the toilet

Sewer Connections

1. remove hose from bumper
2. attach hose to camper
3. attach 90 degree coupling to other end of hose
4. attach coupling to sites sewer

***** It is advised not to open the valves during your stay until the tanks are full or when it is time to leave the site.

Dumping the tanks

1. Black tank (always first)
2. Gray tank

Always dump the black tank first so that the gray tank cleans the sewer hose from any obstructions from the black tank.

If you are connected to water but do not have a sewer connection, be aware that you will have more water than tanks space to store water.

Awning

The awning is electric.

Simply press the “EXT” to extend the awning and “Retr” to bring awning in.

Strong Wind – please do not use in strong winds. Failure to do so this could damage the awning and awning system

Rain – please remember to slant the awning in light rain to allow water to drain off to one side. In Heavy rain please secure and retract awning fully. Failure to do this may cause damage to awning and awning system.

Lights

All lights in the unit are manually operated. There are some lights that are on a wall switch and some are on the light themselves. Lights are also powered by both shore power and battery.

A/C Unit

This unit is equipped with a roof mounted A/C unit. Thermostat is located by the entertainment wall above the water pump switches. Select your function and set your temperature.

Heat

The heating unit of this RV is forced air gas. This means that the propane must be on while in use. To use locate the thermostat by the entertainment wall and select “heat”. Then set your temperature.

TV

The unit does have a tv antenna-built in. Turn the dial to the closest tv tower. Then run a channel search program on your tv and your all set.

Fridge

This fridge can be used on both propane and shore(plug) power. To turn on make sure the power button in the middle of the fridge is on, (auto). When on auto the fridge switches between propane and shore power automatically. If you do not have shore power make sure the “gas” switch is turned on. The thermostat is located inside the fridge on the right side and follow the markings on the fridge. It is not advised to leave the fridge running while the RV is being Towed.